



# PRP-250C


## Thermal Receipt Printer Quick Installation Guide




### Product Overview




TOP




Bottom



Front




Side




Rear  
(USB+RS-232+Ethernet)


### Installing your Printer




#### RS-232



#### USB



#### Ethernet (RJ-45)




### Specification


Model		PRP-250C
Print Method		Thermal line printing
Print Speed		250mm/sec
Print Life		100 Km
Print Font	ASCII Mode	ANK Font.
	Graphic Font	Font A: 12 x 24 dots, Font B: 9 x 17 dots Chinese Character: 24 x 24 dots
Print Resolution		576 dots/line or 512 dots/line
Print Font Character Support		International Font, Big 5 Chinese, GB Chinese
Character Per Line		48 (Font A)/42 (Font B)
Effective Print Width		72mm
Paper Width		79.5mm± 0.5mm
Paper Roll Diameter		≤83mm
Paper Thickness		0.06~0.08mm
Driver		Win 9X/Win ME/Win 2000/Win 2003/Win NT/Win XP/ Win Vista/Win 7/Win 8/Win 10, compatible with EPSON
Print Command Interface		ESC/POS print commands set compatible
Interface		Multi I/O Interface: Serial +Ethernet +USB (UTP)
Cash Drawer		+24VDC/1A, 6-Wire RJ-11
Notification		
Indicator		Audio and LED Indicators
Auto Cutter		Partial
Paper End Notice		Yes
Over-Heat Protection		Yes
Others		
Power Input		+24VDC/2.5A (External Adapter: 100 ~ 240VAC, 50/60Hz)
Color		Black
Compliance		FCC, CE, WEEE, RoHS
Weight		1200g
Dimension (mm)		183.5(L) x 140(W) x 126(H)
Operating Temperature		0°C ~ 45°C
Operating Humidity		10% ~ 80% RH, non-condensing
Storage Temperature		-10°C ~ 60°C
Storage Humidity		10% ~ 90% RH, non-condensing

\* All specifications are subject to change without prior notice.

### Contents



Printer Unit




Power Adaptor



\*Power Cord



\*\*Printer Cable



Paper Roll



Paper Roll Holder



Paper Width Guide




Quick Installation Guide




Utility CD

\* Power Cord is selectable depending on the types of electrical plug.  
\*\* Printer cable is selectable depending on the interface required (RS-232, USB, RJ-45).  
Please refer to the nearest local representatives for further information.



### Installing the Paper Roll



Paper Roll and Paper Roll Holder



Paper Roll Holder  
Paper Roll



Installing the Driver of The Printer

Before installing the driver of your printer, make sure the printer is properly connected to the host PC.

Place the supplied Utility CD into the CD-ROM drive. Browse the CD and open the folder corresponds to the required software.


- 1. Double click the icon “Advanced PRP.exe” to initiate the installation.




- 2. Click “Next” to continue.




- 3. **Select the Operating System:**  
For example: select “Windows 8 Windows 10” for Windows 10 version.  
Click “Install Printer Driver (N)” to continue.




- 4. **Default Printer Setting:**  
To set the printer as the default printer, click the checkbox “Set Default Printer” to confirm.  
Click “Next” to continue.




- 5. **Printer Interface Setting:**  
Select the appropriate communication interface.  
Click “Install” to complete the installation.




- 6. **Installation Completed:**  
Click “OK” to exit the menu.  
It’s recommended restarting the computer after installation is completed.



- 7. **Examine the Port Setting:**  
Remember to access the properties of your printer.  
Make sure the port of printer is correctly configured.



Access sub menu “Ports”, and click to select the correct port for your printer.  
Click “OK” to exit.




**Note:**  
Please refer to the Instruction Manual for further information.

DIP Switch Configuration

To change the setting of the printer manually:

- 1. Turn off the printer.
- 2. Loosen the securing screw of the protective cover.
- 3. Adjust the DIP switches to configure the printer.



DIP	Function	ON	OFF
1	Auto Cutter	No	Yes*
2	Audio Alarm	Yes *	No
3	Print Density	Dark	Light *
4	Two-byte Character Code	No	Yes*
5	Character Per Line	42	48 *
6	Cutter with Cash Drawer	Yes	No *
7 & 8	Baud Rate Setting	---	OFF*

\*\*\* Default Setting

Baud Rate Setting

